

Episode 12 ตอนที่ 5 การส่ง ค่าจาก Webserver มา แสดงผลผ่าน WiFi โดยใช้ Arduino Nano ESP32



NANO ESP32







Connectivity

- Wi-Fi®
- Bluetooth® LE
- Built-in antenna
- 2.4 GHz transmitter/receiver
- Up to 150 Mbps

6.2 Wi-Fi®


The NORA-W106-10B module supports the Wi-Fi® 4 IEEE 802.11 standards b/g/n, with an output power EIRP at up to 10 dBm. The max range for this module is 500 meters.

- 802.11b: 11 Mbit/s
- 802.11g: 54 Mbit/s
- 802.11n: 72 Mbit/s max at HT-20 (20 MHz), 150 Mbit/s max at HT-40 (40 MHz)






SSID: TP-Link_D50B Password: 41624151



192.168.0.116












SSID: TP-Link_D50B Password: 41624151




192.168.0.116











DHT11 Module



```
DHT11 Test.ino
       #include <dhtnew.h>
       DHTNEW mySensor(5); // เชื่อมต่อเซ็นเซอร์ที่ขา D5
        void setup()
          Serial.begin(115200); // อัตราบอดเรตอยู่ที่ 115200
    5
    6
        void loop()
                                                                 โปรแกรมทดสอบโมดูล
    8
                                                                   เซ็นเซอร์ DHT11
            mySensor.read();
    9
            Serial.print("ค่าความชื้นในอากาศ: ");
  10
            Serial.print(mySensor.getHumidity(), 2);
  11
            Serial.println(" %");
  12
            Serial.print("ค่าอุณหภูมิของอากาศ: ");
  13
            Serial.print(mySensor.getTemperature(), 2);
  14
            Serial.println(" องศา");
  15
            delay(1000);
  16
   17
```

Arduino Code - Simple Web Page

```
* Created by ArduinoGetStarted.com
    * This example code is in the public domain
    * Tutorial page: https://arduinogetstarted.com/tutorials/arduino-temperature-via-web
9 #include <WiFiS3.h>
10 #include <OneWire.h>
11 #include <DallasTemperature.h>
12
13 const char ssid[] = "YOUR WIFI"; // change your network SSID (name)
14 const char pass[] = "YOUR WIFI PASSWORD"; // change your network password (use for WPA, or use as key for WE
16 const int SENSOR PIN = 6; // Arduino pin connected to DS18B20 sensor's DQ pin
18 OneWire oneWire (SENSOR PIN); // setup a oneWire instance
19 DallasTemperature tempSensor(&oneWire); // pass oneWire to DallasTemperature library
20
21 int status = WL IDLE STATUS;
22
23 WiFiServer server(80);
24
25 float getTemperature() {
    tempSensor.requestTemperatures();
                                               // send the command to get temperatures
     float tempCelsius = tempSensor.getTempCByIndex(0); // read temperature in Celsius
    raturn tamnCaleine.
```



SimpleWiFiServer